


SOLENOID VALVE

MODELS: 442P & 443P



| PART NO. | DESCRIPTION |
|-----------------|---------------------------------|
| 41-1-8 | KICK-OFF SPRING |
| 41-7-25 | ENCLOSING TUBE (STAINLESS) |
| 41-9-5 | SOLENOID COIL (SPECIFY VOLTAGE) |
| 41-10-11 | PLUNGER |
| 41-15-10 | DIAPHRAGM |
| 41-34 | SPACER RING |
| 41-36-1 | STRAINER SCREEN |
| 41-37 | FLANGE |
| 41-41 | NYLON WASHER |
| 41-35 | SCREEN CAP |
| 41-5-8 | O-RING SEAL |
| 41-16-7 | SCREW |

ACCESSORIES

| | |
|-------|----------------------------------|
| 41-38 | SOLENOID COVER |
| 41-39 | MOUNTING BRACKET |
| 41-40 | SCREW #6-32 X 5/16 LG. (2 REQD.) |